

instant.strong.secure.

thinking inside and outside the box

ROLL IT UP!

Our INSTA Steel Slat Rollshutter Door allows you to easily access the inside of your container.

- Available in 84 inch (2.13 m) width
- Provides convenient and easier access to inside of containers
- Available in white steel
- 1/6 inch (0.4 mm) thickness
- Includes aluminum rail and all hardware including latch lock

#6074 INSTA STEEL SLAT ROLLSHUTTER DOOR

Installation Guide



Tools Required For Installation

- PPE Eye protection, gloves, hearing protection
- Marking tool
- Extension cord
- Drill
- Pliers










- 1. Ensure all PPE (Personal Protective Equipment) is worn.
- Attach the two brackets on the guide rails. The bracket with the tension wheel goes on the left guide rail.
- 3. The other bracket will be attached to the right guide rail.









- Make a hole on the left side of the axle to place a pin. The distance from the inner curtain to the hole is 10 mm (7/16").
- Place the bracket with the spring tension wheel on to the left side of the axle.



www.instacm.com 1.866.647.4353

INSTA Container Modifications is a proud charter member of the National Portable Storage Association (NPSA).









- 1. Place washer between bracket and tension wheel.
- Attach the tension wheel in the axle with self-tapping screws (two selftapping screws will hold it).



instant.strong.secure.

thinking inside and outside the box

ROLL IT UP!

Our INSTA Steel Slat Rollshutter Door allows you to easily access the inside of your container.









- Make another hole on the right side of the axle for a pin. The distance from the inner curtain to the hole is 20 mm (7/8").
- 2. Put the right bracket with guide rail on the right side of the axle and put the pin inside the hole.









- 1. Have two people hold the door guide rails in an upright position.
- 2. Attach the guide rails and brackets on the container wall.
- Pull about 1 m (39 inches) length of the curtain down inside the guide rails. Fix the top and bottom limit.





- 1. Tension the spring.
- 2. Rotate the tension wheel three turns clockwise and hold it with the integrated tension wheel lock plate.
- 3. Attach the latch lock on the curtain at a suitable place.



www.instacm.com 1.866.647.4353



INSTA Container Modifications is a proud charter member of the National Portable Storage Association (NPSA).

WARNING - All products that require installation or fabrication should never be done until you have the product in hand to take exact measurements. While every attempt is made to make sure product specifications are accurate, there is the possibility the products have been updated or a small variance between production made the measurement off from what's in this book. Installation of products may require some fabrication experience, and in no way does warranty cover installation mistakes.